

- The window is built in 2 pieces: The Front Face and the In-Wall Frame. They connect using Buttonfix Connectors.
- Create a rough opening in the wall slightly larger than the dimensions of the In-Wall Frame.
- Bring 120VAC or 24VDC (if power supply is mounted remotely) to the In-Wall Frame.
- Install the frame in the rough opening.
- Bring the Front Face to the frame and hook up to power.
- Now is the time to sync with any smart home device if desired.
- Snap the window back into the frame taking care to just push on the wood frame, not the lens.
- Trim window light like a normal window.

